


 westcott®

FLEX™

QUICK START GUIDE

Table of Contents

Care Instructions & Warranty	3
Items in the Box	4
Dimmer Operation	6
Connecting to a Power Source	8
Frame Assembly for Flex™ Cine Kits	10
Frame Mounting for Flex™ Cine Kits	11
Softbox Assembly	12
Accessories	13



For lighting tips, instructional videos, inspiration, and more, visit WestcottU.com.

Care Instructions & Usage



Shaping Flex Mats

Flex mats are pliable and can be shaped for mounting purposes and to modify light spread. Gently roll and bend the mat into your desired position. Do not crease or sharply fold.



IP64 Rating

Flex mats have an IP rating of 64, which is stated as being protected from total dust ingress and from water spraying from any direction. After contact with water, dry the Flex's surface with a cloth and store in a dry location.



Caution & Warning

- Do not crease.
- Do not sharply fold.
- Do not submerge in water.
- Do not leave in wet conditions for long periods of time.
- Avoid direct contact with any heat source or extreme cold.
- Do not attempt to disassemble.

One-Year Limited Warranty

Westcott's warranty obligations for this product are limited to the terms set forth below: The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the "Westcott" trademark, trade name, or logo affixed to them.

This warranty does not apply: (a) to damage caused by accident, abuse, misuse, flood, fire, earthquake or other external causes; (b) to damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) to a product or part that has been modified to alter functionality or capability without the written permission of Westcott; or (d) to cosmetic damage, including but not limited to scratches, dents and broken plastic.


Please contact Westcott's Repair Department for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the ONE (1) YEAR limited warranty will be returned at the expense of the sender.

Repair Dept.: 800-886-1689 / 419-243-7311 (International)
 E-Mail: info@fjwestcott.com Subject: Attn: Repair Dept.
 Shipping: F.J. Westcott Co, 1425-B Holland Rd, Maumee, OH 43537

Items in the Box

Flex™ 10" x 3", 1' x 1', and 1' x 2' Mats

Item #7430, 7450, 7452, 7492, 7493, 7494




FLEX LED MAT



DIMMER
(STYLES VARY)



POWER ADAPTER




POWER
CORD



CABLE
WRAP

Flex™ 1' x 3' and 2' x 2' Mats

Item #7470, 7490




FLEX LED MAT



POWER ADAPTER
WITH DIMMER



DIMMER
CABLE




POWER
CORD



CABLE
WRAP

Flex™ Cine Sets

Item #7530, 7547, 7531, 7561, 7532, 7533



FLEX LED MAT
WITH DIGITAL DIMMER



SCRIM JIM CINE
FRAME



FULL-STOP
DIFFUSION
CLOTH



DUAL-SOCKET
MAGIC ARM



UNIVERSAL
STUD




16' DIMMER
EXTENSION CABLE




CABLE
WRAP

Flex™ 1' x 1' Cine Kits


Item #7555, 7557, 7550, 7552



(2) FLEX LED MATS
WITH DIGITAL DIMMERS



(2) SCRIM JIM CINE
FRAMES



(2) DUAL-SOCKET
MAGIC ARMS



(2) UNIVERSAL
STUDS



(2) FLEX PORTABLE
SOFTBOXES




(2) FULL-STOP
DIFFUSION CLOTHS



(2) FLEX PORTABLE BATTERIES
(TRAVEL KIT ONLY)



(2) D-TAP CABLES
(TRAVEL KIT ONLY)



(2) TRAVEL STANDS



(2) 16' DIMMER
EXTENSION CABLES




FLEX WHEELED
TRAVEL CASE




(2) CABLE
WRAP

Peter Hurley 4-Light Flex™ Kit

Item #7537




(2) 1' x 2' FLEX LED MATS WITH DIGITAL DIMMERS
(2) 1' x 3' FLEX LED MATS WITH DIGITAL DIMMERS




(2) 1' x 2' SCRIM JIM CINE FRAMES
(2) 1' x 3' SCRIM JIM CINE FRAMES




(4) CABLE
WRAP




(2) 1' x 2' FULL-STOP DIFFUSION CLOTHS
(2) 1' x 3' FULL-STOP DIFFUSION CLOTHS



(4) GRIP HEADS



(4) CENTER
JAW VISE
GRIPS



(4) 16' DIMMER
EXTENSION CABLES



FLEX WHEELED
TRAVEL CASE

Flex™ Dimmer Operation

Dial Dimmer


For 10" x 3" Daylight



Rotate dial clockwise to turn on and increase brightness. Rotate counter-clockwise to decrease brightness and power off the unit.

Digital Dimmer for Flex™ Bi-Color Mats

For 10" x 3" Bi-Color, 1' x 1' Bi-Color, and 1' x 2' Bi-Color



Press until illuminated to control brightness.

When controlling brightness, 0% is the lowest setting and 100% is the highest setting.
When controlling color temperature, 2800K is the warmest setting and 6000K is the coolest setting. For daylight color temperature, set at 5600K. For tungsten color temperature, set at 3200K.


Press until illuminated to control color temperature

Rotate dial clockwise to increase brightness or color temperature. Rotate counter-clockwise to decrease brightness or color temperature.

Power on/off switch

Digital Dimmer for Flex™ Daylight Mats

For 1' x 1' Daylight and 1' x 2' Daylight




Rotate dial clockwise to increase brightness, or counter-clockwise to decrease brightness.

Power on/off switch

Digital Dimmer/Power Supply for Flex™ Daylight Mats

For 1' x 3' Daylight and 2' x 2' Daylight




Rotate dial clockwise to power on and increase brightness. Rotate counter-clockwise to decrease brightness and power off the unit.

Connect Flex™ to a Power Source

To power your Flex LED mat, follow this simple guide for connecting all of your Flex components.


Connecting 10" x 3" Daylight Mats to AC Power

Using included dial dimmer




Connecting 10" x 3" and 1' x 1' Mats to D-Tap Battery

Using included dial, daylight digital, or bi-color digital dimmer




Connecting 10" x 3" Bi-Color, 1' x 1', & 1' x 2' Mats to AC Power

Using included daylight or bi-color digital dimmer



Connecting 1' x 3' and 2' x 2' Mats to AC Power

Using included digital dimmer with built-in power supply




Flex™ Cine Kit Frame Assembly


For superior mounting of Flex 1' x 1' and larger, turn to the Scrim Jim Cine. This modular frame system provides quick and effortless mounting and diffusing of Flex mats both in-studio and on-location. **See page 14 or visit fjwestcott.com for product details.**



1
Locate Components
Begin by locating the included Scrim Jim Cine frame tubes and connectors.



2
Arrange Components
On a flat surface, position frame tubes and connectors next to each other in the proper order. Align the connectors' positive-locking buttons with the button receptacles on the frame tubes.



3
Connect Frame Tubes
Connect any included straight frame connectors with their corresponding frame tubes first. Next, connect each end of a full frame tube to corner connectors. Press and hold the positive-locking button and slide the frame tube into place. The button will 'click' when connected properly.




4
Repeat Corner Connections
Connect the open ends of the parallel frame tubes with 2 corner connectors.



5
Frame Creation
Connect the 2 remaining straight frame tubes to the remaining open ends of the connected corner connectors to create your frame.



6
Attach Flex Mat
Attach your Flex mat to the frame by securing the loop tape to the Flex's front to the hook tape on the frame.



7
Attach Diffusion Fabric (Optional)
Locate the corresponding diffusion fabric. Place the fabric's loop tape edge onto the frame's hook tape. Press to secure.

Flex™ Cine Kit Frame Mounting

A Flex mat attached to a Scrim Jim Cine Frame can be mounted to a light stand or c-stand with a Center Jaw Vise Grip (#1980), or using a Universal Stud (#8539) and Dual-Socket Magic Arm (#2199) or Grip Head (#1881). **See page 15 or visit fjwestcott.com for product details.**

Mounting with Center Jaw Vise Grip



1
Attach Vise Grip to Mount
Securely mount the Vise Grip's shaft in the open socket of the Dual-Socket Magic Arm or Grip Head while attached to a light stand or c-stand.



2
Loosen the Wing Nut
Loosen the Center Jaw Vise Grip's wing nut and separate the vise grip's center jaws.



3
Secure Flex Mat & Frame
Place the Scrim Jim Cine frame with Flex mat between the jaws, ensuring that the frame and mat are aligned with the jaws' grip material. Tighten the wing nut to secure.

Mounting with Universal Stud & Magic Arm



1
Attach Mount to Stand
Attach the Dual-Socket Magic Arm or Grip Head to light stand or c-stand.



2
Attach Stud to Frame
Locate the 3/8"-16 receptacle on your Scrim Jim Cine frame and screw the 3/8"-16-end of the Universal Stud into this receptacle.



3
Attach Stud to Mount
Place the mounted stud into the open socket of the Dual-Socket Magic Arm or Grip Head. Tighten knob to secure.



4
Attach Dimmer to Frame (Optional)
For added convenience, use the included dimmer mounting hardware to streamline your lighting setup. Screw the mounting bolt into a 3/8"-16 receptacle on the Scrim Jim Cine frame. Align the dimmer's rear-mounted bolt receptacle with the mounting bolt and slide into place to attach.

Flex™ Softbox Assembly


Available for 1' x 1', 1' x 2', 1' x 3', and 2' x 2' Flex mats, the Flex Softbox attaches directly to a Scrim Jim Cine frame and light stand. See page 15 or visit fjwestcott.com for product details.



1 Attach Flex to Frame

Begin by attaching your Flex mat to a Scrim Jim Cine frame.

See page 10 for assembly instructions.




2 Attach Softbox Sections

Unfold both sections of the Flex Softbox and attach them at the hook-and-loop flap to create one long section.



3 Attach Softbox

Place the softbox's loop tape edge onto the Flex's rear hook tape edge, ensuring that the frame's 3/8"-16 receptacle aligns with the softbox's grommet. Secure the softbox's hook-and-loop closure on the open corner.



4 Attach Stud to Frame

Screw the 3/8"-16-end of a Universal Stud (#8539) into the frame's 3/8"-16 receptacle.



5 Attach Unit to Mount

Attach the unit to a Dual-Socket Magic Arm (#2199) or Grip Head (#1881) and place onto your preferred stand.

See page 11 for assembly instructions.



6 Attach Diffusion Panel

Attach the diffusion panel's hook tape to the loop tape located on the interior of the Flex Softbox.

Flex™ Accessories



Flex Battery & D-Tap Cable #7424

This compact lithium-ion battery with 12V output weighs under 3 lbs. and includes D-Tap cable and charger.

D-Tap Cable #7423

Cable Wrap #7599



Dimmer Extension Cable

This high-quality, water-resistant cable adds 16' of extension between the Flex Dimmer and Flex LED Mat.


For Flex up to 1' x 2' #7413

For Flex 1' x 3' and 2' x 2' #7436



Wheeled Travel Case #7426

Store Flex mats, Scrim Jim Cine frames, and accessories in this ultra-durable case. Its heavy-duty design features a padded interior for effective storage and travel.



Flex™ Accessories

Scrim Jim Cine™ Frames




FRAME SIZE	SKU	COMPONENTS
1' x 1' Frame Set	1885	(4) 10" Tubes, (4) 2D Corners, (1) Strap
1' x 2' Frame Set	1886	(2) 10" Tubes, (2) 22" Tubes, (4) 2D Corners, (1) Strap
1' x 3' Frame Set	1887	(4) 10" Tubes, (2) 22" Tubes, (2) 2" Straights, (4) 2D Corners, (1) Strap
2' x 2' Frame Set	1889	(4) 22" Tubes, (4) 2D Corners, (1) Strap

See page 10 for Scrim Jim Cine frame assembly.

Scrim Jim Cine™ Diffusion & Grid Cloths

Full-Stop Diffusion



1/4-Stop Grid Cloth



1/2-Stop Grid Cloth



DIFFUSION	SKU
1' x 1' Full-Stop Diffuser	1837
1' x 2' Full-Stop Diffuser	1838
1' x 3' Full-Stop Diffuser	1839
2' x 2' Full-Stop Diffuser	1904

GRID CLOTH	1/4 STOP GRID	1/2 STOP GRID
1' x 1' Grid Cloth	1900	1926
1' x 2' Grid Cloth	1901	1911
1' x 3' Grid Cloth	1902	1912
2' x 2' Grid Cloth	1923	1929

Flex™ Accessories

Flex™ Portable Softboxes

- Effortlessly directs and softens Flex LED output
- Collapses flat for travel
- 1/4-stop diffusion panel included
- Heavy-duty touch fastener mounting strips
- Soft yet durable coated nylon construction
- Mounts to a Scrim Jim Cine frame or Flex mat

SIZE	SKU
1' x 1'	7432
1' x 2'	7433
1' x 3'	7434
2' x 2'	7435

See page 12 for Flex Portable Softbox assembly.



Mounting Hardware



Center Jaw Vise Grip #1980

The Center Jaw Vise Grip quickly clamps onto any point of the Scrim Jim Cine frame for placement in grip heads and arms.



Dual-Socket Magic Arm #2199

The Dual-Socket Magic Arm mounts effortlessly to any light stand or c-stand and can be used in conjunction with the Universal Stud or Vise Grip.



Universal Stud #8539

The Universal Stud's 3/8"-16 thread screws directly into Scrim Jim Cine frame tubes for precise placement of Flex mats and Scrim Jim Cine frames up to 4' x 4'.



Grip Head #1881

This grip head features a heavy-duty design with a torque-locking washer for versatile use with virtually all lighting and grip gear.



Compact Light Stand #7425

This lightweight stand is designed to pair perfectly with Scrim Jim Cine frames up to 2' x 2'.

Thank You!

for purchasing this Westcott® product.


Our promise to you is supported by a commitment to offer the most innovative solutions, exceptional product quality and first class service and support.

Register your purchase.

We have a simple form for registering your Westcott purchase that provides you with added assurance for your gear: [fjwestcott.com/warranty](https://www.fjwestcott.com/warranty)

Visit [fjwestcott.com](https://www.fjwestcott.com)

- Video Tips
- Product Support
- Knowledge Base
- Product Reviews
- Contests & More!



 **westcott**®

[FJWESTCOTT.COM](https://www.fjwestcott.com)