
Optional Accessories

MOUNT





To prevent damaging the lens, when lens mounted don't use a NP-F battery to power the light, but use an external power source through the DC connector.



Quick Start Guide



R300 5€ LED Ring Light

- **Getting Started**
- **Functions**

What's in the box?



R300 SE







Base Case for R300

F&V Europe B.V. Steenovenweg 5, 5708HN Helmond, The Netherlands TM & © F&V All rights reserved.

1 Getting Started

Mounting



Power Two power options ① NP-F Li-ion battery

3 Let's do this!

Turn the light ON
<I> when powering through DC Jack
<II> when using NP-F batteries



2 Functions





R300 5€

R300S 5E

Adjust the Intensity

Use <Intensity> knob to adjust the intensity

2 * Adjust the Color Temperature (only the bi-color version)

Use <Color Temperature> knob to adjust the color temperature